

Check Result Set

02/09/2025 4:42 pm BST

[Relates to version](#)

Tags: 9.0

Check Result Set Line Type

Not all check lists will be relevant for quality, even though it is important to track this for other reasons (e.g., pre-start up H&S checks). The check results set line type allows you to limit the check results sets recorded in an eCHR by *Checklist Type* or *Checklist*.

Triggers

- Check result set is completed/closed. If a live signature is required, this would be when it is signed.
- Check results set is re-closed after an edit.

If an **Insert eSign Profile** is specified then the line in the eCHR containing the check results will require a signature.

The **Check Result Set** line type supports both retrospective signatures and live signatures, meaning that the user on the shopfloor can be required to enter an eSignature when the results set is closed, and as it is committed to eCHR.

Note that if you populate *Insert*, you must also populate *Update* and *Delete* profiles.

Check Results Set - Checklist Version Configuration

There may only be a requirement for specific checklist versions within the designated checklist type to be recorded for quality purposes. The final step toward recording check results within the eCHR is to specify this within the checklist version itself.

Note that as per previous slide, the signature requirements for check results set are specified in the eCHR profile.

Reports

Contents report via the eCHR screen

Check Results Set Line Type– eCHR Listing

Summary Information

17

Check Result Set

Checklist Name: Med Device Dimension checks
No. steps: 2
Version: 1.0

New

Signed

07/08/2025 16:29

1

Revision: 1 (latest)

Content: Formatted Content

Author: Lucy Demo
eSignature Meaning: Approval of Checks Recorded When: 07/08/2025 16:29:17

View Details

Checklist Name: Med Device Dimension...

Checklist Version: 1.0

Workflow: Production (25)

Operation: Test

Drag a column header and drop it here to group by that column:

Check Item	Check Step Name	Criteria	Value	Compulsory	In Conforming	Recorded By	Timestamp
Dimension Check	51	Target: 44 / 1050 / 45 / 130 / 44	44.5	Yes	Yes	Lucy Demo	07/08/2025 16:38
Check Base width	51	Target: 36 / 1050 / 25 / 130 / 23	36	Yes	Yes	Lucy Demo	07/08/2025 16:38

Detailed Information

Check Results Set Line Type – Printable Report

Summary Information

Line Type	Latest	Revision	Reason	Signature Status	Created	Details	Last Edit User	eSign
Check Result Set	Yes	1	New	Signed	07/08/2025 15:29:17	Checklist Name: Med Device Dimension checks No. steps: 2 Version: 1.1	Lucy Demo	Author: Lucy Demo Meaning: Approval of Checks Recorded Where: 07/08/2025 14:29:17

Steps

Check Item	Check Step Name	Criteria	Value	Compulsory	Is Conforming	Recorded By	Timestamp
Dimension Check	S1	Target: 44 / USL: 45 / LSL: 44	44.5	Yes	Yes	Lucy Demo	07/08/2025 16:28:16
Check Base width	S1	Target: 24 / USL: 25 / LSL: 23	24	Yes	Yes	Lucy Demo	07/08/2025 16:28:20

Detailed Information