

Tool Use

02/09/2025 4:45 pm BST

[Relates to version](#)

Tags: 9.0

Tool Use

Not all tool uses will be relevant for quality, even though it is important to track use/location (e.g. use of a lifting tool or jig may not be required for eCHR quality assurance).

The **Tool Use** line type allows you to limit the tool uses recorded in to a specific **Tool Type** or **Tool Group**.

Triggers

Creation or change of a tool use log linked to the item while the eCHR is open.

Reports

Contents report via the eCHR screen

Issue Line Type – eCHR Listing

Summary Information

11	Tool Use	Tool Name: MED1 Tool Type: Medical sterilisation tool Tool Serial No: MED1 Timestamp: 07/08/2025 14:28:47 No. Uses: 1	New	Not Required	07/08/2025 13:28	1	-
----	----------	---	-----	--------------	------------------	---	---

Detailed Information

Revision: 1 (Latest) | Content: Formatted Content | eSignature: Not Available

Operation Number	Operation Name	Tool Name	Tool Type	Tool Serial	Timestamp	Recorded By	Number of Uses
20	Assembly	MED1	Medical sterilisation tool	MED1	07/08/2025 14:28	Lucy	1

HTML Report

Issue Line Type – Printable Report

Summary Information

Line Type	Latest	Revision	Reason	Signature Status	Created	Details	Last Edit User	eSign
Tool Use	Yes	1	New	Not Required	07/08/2025 13:28:49	Tool Name: MED1 Tool Type: Medical sterilisation tool Tool Serial No: MED1 Timestamp: 07/08/2025 14:28:47 No. Uses: 1	Lucy Demo	

Details

Operation Number	Operation Name	Tool Name	Tool Type	Tool Serial	Timestamp	Recorded By	Number of Uses
20	Assembly	MED1	Medical sterilisation tool	MED1	07/08/2025 14:28:47	Lucy	1

Detailed Information